


# MT20 (SDI-12 Interface)

Soil Moisture, EC and Temperature Sensor (MT20A)

Soil Moisture, Temperature Sensor (MT20B)

User Manual V6.01



# Index

|   |  |           |
|---|--|-----------|
| 1 | Customer Support.....  | 3         |
| 2 | Introduction .....   | 4         |
| 3 | Wiring diagrams .....  | 5         |
| 4 | Dimension and Ordering Infomation .....                          | 6         |
|   | <b>4.1 Dimension .....</b>                                       | <b>6</b>  |
|   | <b>4.2 Ordering Information.....</b>                             | <b>6</b>  |
| 5 | Safty ,Care and Installation .....                               | 8         |
|   | <b>5.1 Care and Safty.....</b>                                   | <b>8</b>  |
|   | <b>5.2 Installation.....</b>                                     | <b>8</b>  |
| 6 | Output Signal Conversion .....                                   | 9         |
|   | <b>6.1 Water Content Conversion for Soil.....</b>                | <b>9</b>  |
|   | <b>6.2 Water Content Conversion for Non-soil substrate .....</b> | <b>9</b>  |
| 7 | Communication interface and Protocol.....                        | 10        |
|   | <b>7.1 ADI Interface and Protocol.....</b>                       | <b>10</b> |
|   | 7.1.1 ADI Interface.....   | 10        |
|   | 7.1.2 Protocol .....   | 11        |
|   | <b>7.2 SDI-12 Interface and Protocol .....</b>                   | <b>12</b> |
|   | 7.2.1 SDI-12 Interface.....                                      | 12        |
|   | 7.2.2 Protocol .....   | 12        |
|   | Appendix .....   | 16        |
|   | <b>Copyright and Trademark.....</b>                              | <b>16</b> |
|   | <b>Version Control.....</b>                                      | <b>16</b> |

# 1 Customer Support

Thank you very much for your order. Our success comes from the continuous faith in the excellence of our products and services, something we are committed to and would never sacrifice. Our customer service, especially in the after sales phase, guarantees the satisfaction of our clients. In line with this strategy, we appreciate that you can share with us your feedback at any time for our improvement, be it positive or negative, so if we can serve you better in anyway, please do inform us.

## **Website**

<http://www.infwin.com>

## **E-Mail**

[infwin@163.com](mailto:infwin@163.com)

## **Telephone**

+86-411-66831953, +86-4000-511-521

## **Fax**

+86-411-82388125




## 2 Introduction

MT20 is a sensor with SDI-12 interface, measuring soil moisture content, temperature and EC, or soil moisture content and temperature regarding the order information. It sealed with resin packaged plastic body with sensing rods which can be insert directly into the soil with long time stability., The sensor is applicable for science research, irrigation, greenhouse, smart agriculture etc.

- Integrated with Soil Moisture, temperature or with EC measurement
- Output Interface SDI-12
- Low salinity sensitivity
- Minimal soil disturbance
- Water proof to IP68 ratings and can be directly buried into soil
- High accuracy with excellent stability
- Reverse power protection and Built-in TVS/ESD protection
- ODM/OEM Service


| <b>Specifications</b>            |   |
|----------------------------------|---|
| <b>Output Interface</b>          | SDI-12, V1.3  |
| <b>Power Supply</b>              | 3.6-16V/DC  |
| <b>Power Consumption</b>         | Quiescent Current : 30uA<br>Measuring Current : 10mA during 150ms measurement   |
| <b>Soil Moisture Measurement</b> | Apparent dielectric permittivity ( $\xi_a$ ):<br>Range:1-81 (air - water)<br>Resolution:1.00-40.00:±0.1,40.00-81.00:±0.5<br>Accuracy:1.00-40.00:±2%,40.00-81.00:±5%<br><br>Soil Moisture(VWC):<br>Range:0%-100% (air - water)<br>Resolution:derived by the conversion function from epsilon to VWC<br>Accuracy:derived by the conversion function from epsilon to VWC |
| <b>EC Measurement</b>            | Range: 0-23ds/m<br>Resolution: 0-7ds/m, 0.01ds/m; 7-23ds/m, 0.05ds/m<br>Accuracy: 0-7ds/m, 5%; 7-23ds/m,15%<br>EC temperature compensation: 0-50°C  |
| <b>Temperature Measurement</b>   | Range: -40~80°C, Resolution:0.1°C, Accuracy:±0.5°C  |
| <b>Measurement Technique</b>     | Moisture by FDR and EC by AC excitation   |
| <b>IP Ratings</b>                | IP68  |
| <b>Operating Temperature</b>     | -40~85°C  |
| <b>Sensor Rod</b>                | Stainless steel   |
| <b>Sensor Sealed</b>             | Epoxy resin   |
| <b>Installation</b>              | Surface or buried installation  |
| <b>Cable Length</b>              | 5 meters or Customize   |
| <b>Dimension</b>                 | 88*71*26mm  |

### 3 Wiring diagrams

| Type                           | Wiring diagram  |
|--------------------------------|---|
| <p><b>SDI-12 Interface</b></p> | <p><b>Cold pressed terminal and tinned lead wires</b></p>  <p><b>3.5 mm stereo plug</b></p>  |
| <p><b>Connections</b></p>      | <p><b>Wiring Diagram</b></p>    |

## 4 Dimension and Ordering Information

### 4.1 Dimension



### 4.2 Ordering Information

| Parameters                      | Code        | Comments  |
|---------------------------------|-------------|---|
| Code 1:<br>Product Series       | MT20        | MT20 SDI-12 interface sensor  |
| Code 2:<br>Measuring Parameters | A<br>B      | Soil Moisture & Temperature & EC<br>Soil Moisture & Temperature             |
| Code 3:<br>Soil Moisture Range  | B           | 0-100%  |
| Code 4:<br>EC Range             | C<br>X      | 0-23ds/m<br>No EC measurement(select this if do not need EC)                |
| Code 5:<br>Power Supply         | B           | 3.6-16V DC  |
| Code 6:<br>Connector            | A<br>B<br>C | 3.5 mm stereo plug<br>Cold pressed terminal<br>Stripped & tinned lead wires |
| Code 7:<br>Cable Length         | 005<br>XXX  | 5 meters<br>Customize, XXX is required cable length(Unit: meter)            |

Ordering Code Example:

MT20 SDI-12 interface sensor, Soil Moisture & Temperature & EC, Soil Moisture Range 100%, EC range 0-23ds/m, Power supply 3.6-16V DC, 3.5 mm stereo plug, Cable length 5 meters. Ordering Code is : MT20 – A B C B A 005

## 5 Safty ,Care and Installation

### 5.1 Care and Safty

- The rods of the Sensor are sharp for ease insertion. Care must be taken and handling precautions followed.
- Avoid touching the rods or exposing them to other sources of static damage, particularly when powered up.
- Do not pull the sensor out of the soil by its cable.
- If you feel any resistance when inserting the sensor into soil, it is likely you have encountered a stone. Stop pushing and re-insert at a new location.

### 5.2 Installation

#### Surface installation

- Clear away any stones. Pre-form holes in very hard soils before insertion.
- Push the sensor into the soil until the rods are fully inserted. Ensure good soil contact.
- If you feel strong resistance when inserting the sensor, you have probably hit a stone. Stop, and re-insert at a new location.

Note: The sensor is suitable for soil surface temperature measurements.

#### Installing at depth

- Make a 45mm diameter hole, preferably at about 10° to the vertical using a auger.
- Push the sensor into the soil until rods are fully inserted. Ensure good soil contact.
- Fill and repack the hole with soil.

#### Alternatively

- Dig a trench, and install horizontally.



## 6 Output Signal Conversion

| Output Interface | Parameters Range  | Conversion Formula            |
|------------------|---|-------------------------------|
| SDI-12           | Apparent dielectric permittivity<br>$\xi_a$ :0.88-81.88 | Character string 0.88-81.88   |
|                  | Temperature:-40.00-80.00°C                              | Character string -40.00-80.00 |
|                  | EC:0-20.00ds/m  | Character string 0-20.00      |

Note: VWC can be calculated by  $\xi_a$  using formula below.

Note: VWC is volumetric water Content ranges from 0-100%,  $\xi_a$  is Apparent dielectric permittivity measured by sensor.

### 6.1 Water Content Conversion for Soil

Using following conversion formula for VWC calculation.

$$VWC = 4.3 * 10^{-6} * \xi_a^3 - 5.5 * 10^{-4} * \xi_a^2 + 2.92 * 10^{-2} * \xi_a - 5.3 * 10^{-2}$$

### 6.2 Water Content Conversion for Non-soil substrate

Using following conversion formula for VWC calculation.

#### ■ Potting Soil

$$VWC = 2.25 * 10^{-5} * \xi_a^3 - 2.06 * 10^{-3} * \xi_a^2 + 7.24 * 10^{-2} * \xi_a - 0.247$$

#### ■ Rockwool

$$VWC = -1.68 * 10^{-3} * \xi_a^2 + 6.56 * 10^{-2} * \xi_a + 0.0266$$

#### ■ Perlite

$$VWC = -1.07 * 10^{-3} * \xi_a^2 + 5.25 * 10^{-2} * \xi_a - 0.0685$$


# 7 Communication interface and Protocol

The sensor has two type of serial interface and protocol, ADI protocol(Active Digital Interface)and SDI-12 Protocol.


## 7.1 ADI Interface and Protocol

### 7.1.1 ADI Interface

ADI interface protocol(TTL signal),ADI is short for Active Digital Interface. Each time when sensor power up with SDI-12 address 0,the sensor firstly enter into the ADI mode and pull down the SDI-12 signal line for 100ms to indicating the measurement in processing,then release the SDI-12 signal line and output the ADI protocol data, and then enter into the SDI-12 interface mode.



ADI interface is TTL compatible standard(0-3.6V),protocol data stream is encoded in ASCII,Baudrate 1200bps,None parity,8 data bits,1 stop bit.The sensor enter into SDI-12 standby mode after the ADI output.You'll need to re power up the sensor again for another ADI output.ADI interface transmission bit diagram is as following.



## 7.1.2 Protocol

The data stream protocol including 3 raw measurement data with space delimited, and terminated by the carriage return.

The first data is Epsilon raw value. The second data is EC raw value(will be always 0 for those sensors without EC measurement),The third data is Temperature raw value. Those raw data can be converted to the measurement values by following formulas:

- Epsilon  $\xi_a$

Epsilon raw value ranges from 0~4094 (and 4095 to indicate the error),and can be converted to epsilon value  $\xi_a$  0.00~81.88 :

$$\xi_a = (\text{Epsilon raw value})/50.00$$

- EC<sub>(bulk)</sub>

EC raw value ranges from 0~1022(and 1023 to indicate the error),and can be converted to EC<sub>(bulk)</sub> 0.00~23.10ds/m :

When  $EC_{raw} \leq 700$  then  $EC_{(bulk)} = EC_{raw}/100$

When  $EC_{raw} > 700$  then  $EC_{(bulk)} = \frac{700 + 5 (EC_{raw} - 700)}{100}$

The unit of EC is:ds/m

- Temperature

Temperature raw value ranges from 0~1022(and 1023 to indicate the error),when temperature in -40.0~50.0°C, resolution is 0.1°C;when temperature in 50.5~111.0°C, resolution is 0.5°C :

When  $T_{raw} \leq 900$  then  $T_{Raw2} = T_{Raw}$

When  $T_{raw} > 900$  then  $T_{Raw2} = 900 + 5 (T_{Raw} - 900)$

$$\text{Temperature } T(^{\circ}\text{C}) = \frac{(T_{Raw2} - 400)}{10}$$

Example: Data stream sent by sensor, “56 432 645<0D>zG<0D><0A>”

| Parameters                  | Comment  |
|-----------------------------|--|
| <b>56</b>                   | $\xi_a = \text{EPSILON}_{raw}/50.00 = 56/50 = 1.12$ ,and then using proper formula to convert $\xi_a$ to VWC   |
| Space                       | data delimiter   |
| <b>432</b>                  | $EC_{raw} = 432 \leq 700$ , then $EC_{(bulk)} = EC_{raw}/100 = 432/100 = 4.32\text{ds/m}$  |
| Space                       | data delimiter   |
| <b>645</b>                  | $T_{raw} = 645 \leq 900$ then $T_{Raw2} = T_{Raw} = 645$<br>And then temperature $T(^{\circ}\text{C}) = \frac{(T_{Raw2} - 400)}{10} = \frac{(645 - 400)}{10} = 24.5^{\circ}\text{C}$ |
| <b>&lt;0D&gt;</b>           | Carriage return  |
| <b>z</b>                    | Sensor type indicator.<br>'z' is MT20A<br>'x' is MT20B   |
| <b>G</b>                    | Checksum of string “56 432 645<0D>z” for transmission validation.  |
| <b>&lt;0D&gt;&lt;0A&gt;</b> | Carriage return,is the data stream terminator  |

ADI Interface checksum calculation:

```
char CalcADIChecksum(char * Response)
{
    int length, sum = 0, i, crc;
    // stream data length
    length = strlen(Response);
    // checksum calculation
    for( i = 0; i < length; i++ )
        sum += Response[i];
    // convert to printable character
    crc = sum % 64 + 32;
    return crc;
}
```

Using “56 432 645<0D>z” as function parameters “char \* Response” and you will get a checksum ‘G’

## 7.2 SDI-12 Interface and Protocol

### 7.2.1 SDI-12 Interface

Please refer to SDI-12 standard user manual V1.3.

### 7.2.2 Protocol

| Request | Response                                     | Comment   |
|---------|--|---|
| a!      | a<CR><LF>                                    | Acknowledge Active<br>a: Sensor address<br><b>Example:</b><br>Request: 0!<br>Response: 0<CR><LF>  |
| a!      | allccccccmmmmmmvxxxxxxxxxxxx<br>xxxx<CR><LF> | Send Identification<br>a: Sensor address<br>ll:SDI-12 Version Number<br>ccccccc: 8 characters vendor identification<br>mmmmmm: 6 characters specifying the sensor model number<br>vvv: 3 characters specifying the sensor version<br>xxxxxxxxxxxxx: 13 characters serial number<br><CR><LF>: terminates the response<br><b>MT20A Example:</b><br>Request: 0!<br>Response: 013INFWIN MT20A<br>1.01909250001000<CR><LF> |

|      |  |   |
|------|--|---|
|      |  | <p><b>MT20B Example:</b><br/>Request: 0I!<br/>Response: 013INFWIN MT20B<br/>1.01909250001000&lt;CR&gt;&lt;LF&gt;</p>  |
| ?!   | a<CR><LF>  | <p>Sensor Address Query<br/>a:Sensor address<br/><b>Example:</b><br/>Request: ?!<br/>Response: 0&lt;CR&gt;&lt;LF&gt;</p>  |
| aAb! | b<CR><LF>  | <p>Change Sensor address<br/>a:Current Sensor address<br/>b:New Sensor address<br/><b>Example:</b><br/>Request: 0A1!<br/>Response: 1&lt;CR&gt;&lt;LF&gt;</p>  |
| aM!  | <p>attn&lt;CR&gt;&lt;LF&gt;</p> <p>a:Sensor address<br/>ttt: Measurement data will be ready in<br/>ttt seconds<br/>n:Number of measurement data<br/>&lt;CR&gt;&lt;LF&gt;:terminates the response</p> | <p><b>MT20A Example:</b><br/>Start Measurement Command. 3 data will be ready in<br/>001 seconds.<br/>Request: 0M!<br/>Response: 00013&lt;CR&gt;&lt;LF&gt;<br/>Response: 0&lt;CR&gt;&lt;LF&gt;<br/>Request: 0D0!<br/>Response: 0+23.53+2.60+17.6&lt;CR&gt;&lt;LF&gt;<br/>Epsilon=23.53<br/>EC=2.60ds/m<br/>Temperature=17.6°C</p> <p><b>MT20B Example:</b><br/>Start Measurement Command. 2 data will be ready in<br/>001 seconds.<br/>Request: 0M!<br/>Response: 00012&lt;CR&gt;&lt;LF&gt;<br/>Response: 0&lt;CR&gt;&lt;LF&gt;<br/>Request: 0D0!<br/>Response: 0+18.96+18.0&lt;CR&gt;&lt;LF&gt;<br/>Epsilon=18.96<br/>Temperature =18.0°C</p> |
| aMC! | <p>attn&lt;CR&gt;&lt;LF&gt;</p> <p>a:Sensor address<br/>ttt: Measurement data will be ready in<br/>ttt seconds<br/>n:Number of measurement data<br/>&lt;CR&gt;&lt;LF&gt;:terminates the response</p> | <p><b>MT20A Example:</b><br/>Start Measurement and Request CRC. 3 data will be<br/>ready in 001 seconds.<br/>Request: 0MC!<br/>Response: 00013&lt;CR&gt;&lt;LF&gt;<br/>Response: 0&lt;CR&gt;&lt;LF&gt;<br/>Request: 0D0!<br/>Response: 0+23.53+2.60+17.6Bou&lt;CR&gt;&lt;LF&gt;</p>   |

|      |  |  |
|------|--|--|
|      |  | <p><b>MT20B Example:</b><br/> Start Measurement and Request CRC. 2 data will be ready in 001 seconds.<br/> Request: 0MC!<br/> Response: 00012&lt;CR&gt;&lt;LF&gt;<br/> Response: 0&lt;CR&gt;&lt;LF&gt;<br/> Request: 0D0!<br/> Response: 0+18.96+18.0Mtu&lt;CR&gt;&lt;LF&gt;</p>   |
| aC!  | <p>atttn&lt;CR&gt;&lt;LF&gt;</p> <p>a:Sensor address<br/> ttt: Measurement data will be ready in ttt seconds<br/> n:Number of measurement data<br/> &lt;CR&gt;&lt;LF&gt;:terminates the response</p> | <p><b>MT20A Example:</b><br/> Start Concurrent Measurement.3 data will be ready in 001 seconds.<br/> Request: 0C!<br/> Response: 00013&lt;CR&gt;&lt;LF&gt;<br/> Request: 0D0!<br/> Response: 0+23.53+2.60+17.6&lt;CR&gt;&lt;LF&gt;</p> <p><b>MT20B Example:</b><br/> Start Concurrent Measurement.2 data will be ready in 001 seconds.<br/> Request: 0C!<br/> Response: 00012&lt;CR&gt;&lt;LF&gt;<br/> Request: 0D0!<br/> Response: 0+18.96+18.0&lt;CR&gt;&lt;LF&gt;</p>   |
| aCC! | <p>atttn&lt;CR&gt;&lt;LF&gt;</p> <p>a:Sensor address<br/> ttt: Measurement data will be ready in ttt seconds<br/> n:Number of measurement data<br/> &lt;CR&gt;&lt;LF&gt;:terminates the response</p> | <p><b>MT20A Example:</b><br/> Start Concurrent Measurement and Request CRC.3 data will be ready in 001 seconds.<br/> Request: 0CC!<br/> Response: 00013&lt;CR&gt;&lt;LF&gt;<br/> Request: 0D0!<br/> Response: 0+23.53+2.60+17.6Bou&lt;CR&gt;&lt;LF&gt;</p> <p><b>MT20B Example:</b><br/> Start Concurrent Measurement and Request CRC.2 data will be ready in 001 seconds.<br/> Request: 0CC!<br/> Response: 00012&lt;CR&gt;&lt;LF&gt;<br/> Request: 0D0!<br/> Response: 0+18.96+18.0Mtu&lt;CR&gt;&lt;LF&gt;</p> |
| aD0! | <p>a[&lt;saaaa&gt;][&lt;sbbbb&gt;][&lt;scccc&gt;][&lt;CRC&gt;]&gt;&lt;CR&gt;&lt;LF&gt;</p>   | <p>Send Data Command, The sensor responds by sending the data<br/> The data returned depends on the command you send most recently.<br/> [&lt;saaaa&gt;]: data 1<br/> [&lt;sbbbb&gt;]: data 2</p>  |

|       |   |  |
|-------|---|--|
|       |   | <p>[&lt;scccc&gt;]: data 3<br/>                 [&lt;CRC&gt;]: Optional 3 characters CRC checksum,<br/>                 &lt;CR&gt;&lt;LF&gt;:terminates the response</p>   |
| aR0!  | <p><b>For MT20A:</b><br/>                 a&lt;saaaa&gt;&lt;sbbbb&gt;&lt;scccc&gt;&lt;CR&gt;&lt;LF&gt;<br/>                 &lt;saaaa&gt;:Epsilon<br/>                 &lt;sbbbb&gt;:EC<br/>                 &lt;scccc&gt;:Temperature</p> <p><b>For MT20B:</b><br/>                 a&lt;saaaa&gt;&lt;sbbbb&gt;&lt;CR&gt;&lt;LF&gt;<br/>                 &lt;saaaa&gt;:Epsilon<br/>                 &lt;sbbbb&gt;:Temperature</p>  | <p><b>MT20A Example:</b><br/>                 Continuous Measurements, and return data<br/>                 Request: 0R0!<br/>                 Response: 0+23.53+2.60+17.6&lt;CR&gt;&lt;LF&gt;</p> <p><b>MT20B Example:</b><br/>                 Continuous Measurements, and return data<br/>                 Request: 0R0!<br/>                 Response: 0+18.96+18.0&lt;CR&gt;&lt;LF&gt;</p>   |
| aRC0! | <p><b>For MT20A:</b><br/>                 a&lt;saaaa&gt;&lt;sbbbb&gt;&lt;scccc&gt;&lt;CRC&gt;&lt;CR&gt;&lt;LF&gt;<br/>                 &lt;saaaa&gt;:Epsilon<br/>                 &lt;sbbbb&gt;:EC<br/>                 &lt;scccc&gt;:Temperature<br/>                 &lt;CRC&gt;:CRC checksum</p> <p><b>For MT20B:</b><br/>                 a&lt;saaaa&gt;&lt;sbbbb&gt;&lt;CRC&gt;&lt;CR&gt;&lt;LF&gt;<br/>                 &lt;saaaa&gt;:Epsilon<br/>                 &lt;sbbbb&gt;:EC<br/>                 &lt;CRC&gt;:CRC checksum</p> | <p><b>MT20AExample:</b><br/>                 Continuous Measurements and Request CRC, and return data.<br/>                 Request: 0RC0!<br/>                 Response: 0+23.53+2.60+17.6Bou&lt;CR&gt;&lt;LF&gt;</p> <p><b>MT20BExample:</b><br/>                 Continuous Measurements and Request CRC, and return data.<br/>                 Request: 0RC0!<br/>                 Response: 0+18.96+18.0Mtu&lt;CR&gt;&lt;LF&gt;</p> |

# Appendix

## Copyright and Trademark

This document is copyrighted, 2019, by Dalian Endeavour Technology Co., Ltd. All rights are reserved. Dalian Endeavour Technology Co., Ltd. reserves the right to make improvements to the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission. Information provided in this manual is intended to be accurate and reliable. However, Dalian Endeavour Technology Co., Ltd. assumes no responsibility for its use, nor for any infringements upon the rights of third parties, which may result from its use.

INFWIN® is the trademark of Dalian Endeavour Technology Co., Ltd.

## Version Control

| <b>Date</b> | <b>Version</b> | <b>Comment</b>   | <b>Updated by</b> |
|-------------|----------------|------------------|-------------------|
| 2015-04-23  | V6.01          | Initial Creation | fg49597           |